

WALL BRACKETS – Fitting Instructions

PLEASE READ THESE INSTRUCTIONS RIGHT THROUGH BEFORE STARTING.

SOME EARLY STEPS MAY BE AFFECTED BY LATER ONES.

These instructions are produced as a guide only.

You will be provided with a pair of wall brackets, with a small black adjuster screw fitted and an allen key.

You will require two people to handle the wall cabinet furniture.

- 1) Decide the position that the units are to be fixed to the wall. Hold the unit up to the wall (this will require two people) and using a pencil make a small mark on the wall level with the top of the unit and in the centre of the top of the unit.
- 2) Measure down from the mark 37mm and mark the wall again.
- 3) Using a spirit level, draw a line on the wall either side the lower mark, the length of the line being just short of the width of the unit.
- 4) On the back of the wall unit there are two silver coloured hanging brackets. Measure the distance between the centres of the two hanging brackets, and make a note of this measurement.
- 5) On the line drawn on the wall, mark out where the centre of the unit is to be, and then mark out equal distance either side of the centre line mark, the measurement taken in instruction 4.
- 6) Place the loose silver coloured wall bracket on the wall up to the top line drawn, and line the centre of the wall bracket up to the L/H mark on the wall, with the top edge of the horizontal bar on the bracket level with the line. Ensure that the adjuster screw tab is pointing upwards.
- 7) Whilst holding the bracket in position, mark the wall through the two screw holes on the brackets. These holes mark the positions for drilling the wall for the plugs and screws.
- 8) Repeat Instruction 6 and 7 for the right-hand wall bracket.
- 9) Using the correct masonry drill bit for the appropriate wall plugs, drill out the two holes as marked on the wall for each bracket. Ensure the depth of the hole is correct for the length of plug and screw.
- 10) Tap the wall plugs into the drilled holes.

WALL BRACKETS – Fitting Instructions

- 11) Line the wall brackets up to the holes and screw to the wall using the appropriate screws.
- 12) Lift the wall cabinet up to position on the wall, and hook the silver coloured hanging brackets on the back of the cabinet over the fixed silver wall brackets.
- 13) Check that the top of the cabinet is at the required height, and also, using the spirit level ensure that the cabinet is level on the wall.
- 14) If the unit is too high on the right side, lift the unit back off the wall brackets, and aside to the floor. Please always ensure that you have assistance when lifting the unit.
- 15) Slacken off the screw, which is in the slot on the right hand bracket, and swing the right hand side of the bracket downward (or upwards if the unit is too low on the wall).
- 16) The same can be done on the left hand bracket if required, until the unit is level on the wall.
- 17) The distance that the unit sits off the wall at the top, can be adjusted by screwing the black adjuster screw fitted onto the wall bracket, using the allen key provided. Screw the black adjuster screw in to move the unit closer to the wall, or out to push the unit away from the wall.
- 18) The distance that the unit sits off the wall at the top, can be adjusted by screwing the plastic adjuster screws positioned at the bottom corners of the unit in or out. Screw in to move the unit closer to the wall, or out to push the unit away from the wall.
- 19) Repeat the above process for additional cabinets, which may fit either side of the unit now fixed in place.
- 20) If runs of units are to be fixed to the wall in a line, then it is best to draw the wall bracket positioning line all the way along the wall, spanning the entire length of the run of units.